


Moisture & Water Control: 3 Methods to Evaluate Your Wall Assemblies



In accordance with the Department of Labor and Industry's statute 326.0981, Subd. 11,

“This educational offering is recognized by the Minnesota Department of Labor and Industry as satisfying **1.5 hours** of credit toward **Building Officials and Residential Contractors** continuing education requirements.”

For additional continuing education approvals, please see your credit tracking card.

Outline – Moisture & Water Control

1. Building Science Review
2. Qualitative Moisture Assessment
3. Glaser Analysis
4. WUFI Analysis
5. Summary and recap

Section 1 – Building Science Review

What is the function of the building enclosure?

Section 1 – Building Science Review

What is the function of the building enclosure?

Structural Strength + Occupant Safety

Environmental Separation
(HAM + solar radiation)

Durability + Sustainability

Aesthetics

Section 1 – Building Science Review

What is the function of the building enclosure?

Structural Strength + Occupant Safety


Environmental Separation
(HAM + solar radiation)

Durability + Sustainability

Aesthetics


Section 1 – Building Science Review

arranged in order of significance - Wetting pathways




Section 1 – Building Science Review

Drying pathways – arranged in order of significance



Section 1 – Building Science Review

How do we control these two in a modern wall?



Section 1 – Building Science Review

...Drainage cavity behind cladding, with ventilation

- 1) Allows any water leakage that does happen to drain out of the assembly.
- 2) Stops capillary moisture drive.
- 3) Ventilation aids evaporation and removes moisture.





Image credit – CEI Composite Materials



Section 1 – Building Science Review

How do we control these two for a wall?




Section 1 – Building Science Review

...Frequently 6 mil poly

- 1) Poly is most often used as both the vapor retarder AND air barrier
- 2) Not a durable product - frequently punctured
- 3) Difficult to install in an airtight manner
- 4) More impermeable than is really needed – can restrict diffusion drying



Section 1 – Building Science Review




Air Leakage vs. Diffusion

Air leakage has the potential to introduce many times more water into a wall than diffusion.

Controlling air leakage is important not just for energy savings, but for the long term moisture durability of highly-insulated envelopes.

Section 1 – Building Science Review



Air Leakage vs. Diffusion

Air leakage has the potential to introduce many times more water into a wall than diffusion.

Controlling air leakage is important not just for energy savings, but for the long term moisture durability of highly-insulated envelopes.

Where does all this water go?

- Some escapes with the air
- In the winter, much of it “condenses” on the first cold surface, typically the sheathing.

Section 1 – Building Science Review


Air leakage vs. Diffusion

It can be a confusing topic.


Air leakage is the movement of air through a hole in the enclosure, driven by a difference in air pressure.

As the air moves, it takes moisture with it.

WATER VAPOR DIFFUSION




Initial Conditions: The higher temperature and water vapor content in the left chamber causes a vapor pressure gradient toward the right and drives the water vapor molecules through the vapour retarder.




Equilibrium Conditions: After several hours or days, the higher concentration of water vapor molecules continues diffusing until a vapor pressure equilibrium is reached across both chambers.

MOISTURE MIGRATION BY AIR LEAKAGE



Initial Conditions: The left chamber is at a higher air pressure than the right chamber. Any puncture in the air barrier will result in both air and water vapor molecules migrating to the right chamber.




Equilibrium Conditions: After several seconds, the air/vapor mixture leaks from the left chamber into the right chamber until air pressure equilibrium is reached across both chambers.

Section 1 – Building Science Review

Air leakage vs. Diffusion


It can be a confusing topic.

Diffusion is the transport of water vapor through a material, molecule by molecule, driven by difference in vapor pressure.



Section 1 – Building Science Review

After bulk water leakage, capillary movement, and air leakage are controlled, diffusion wetting and drying should be considered.



Section 1 – Building Science Review

Here are some basic rules for cold climates:

- 1) A class I or class II **warm** side vapor retarder is required in most cases
- 2) Don't create a “vapor sandwich”

Norwegian building code requires exterior layers of sheathing and insulation to be 10x more vapor permeable than the warm side vapor retarder.

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior XPS (pink or blue foam) be applied?

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior XPS (pink or blue foam) be applied?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior EPS (white Styrofoam) be applied?

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior EPS (white Styrofoam) be applied?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior foil-faced polyiso be applied?

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior foil-faced polyiso be applied?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**
- 1 inch of foil faced polyiso (0.05 perms) is less permeable than the poly - **FAILS!!!**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can 1 inch of exterior mineral wool be applied?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**
- 1 inch of foil faced polyiso (0.05 perms) is less permeable than the poly - **FAILS**
- 1 inch of mineral wool (100 perms) is 1000x more vapor open- **PASSES (easily)**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can OSB be used as the exterior sheathing?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**
- 1 inch of foil faced polyiso (0.05 perms) is less permeable than the poly - **FAILS**
- 1 inch of mineral wool (100 perms) is 1000x more vapor open- **PASSES**

- OSB sheathing (1.0 perms) is exactly 10x more vapor open – **PASSES**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can fiberglass-faced gypsum board (like DensGlass Gold) sheathing be used?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**
- 1 inch of foil faced polyiso (0.05 perms) is less permeable than the poly - **FAILS**
- 1 inch of mineral wool (100 perms) is 1000x more vapor open- **PASSES**

- OSB sheathing (1.0 perms) is exactly 10x more vapor open – **PASSES**
- DensGlass Gold, fire-rated type X (12 perms) is 120x more vapor open – **PASSES**

Section 1 – Building Science Review

Testing the 10x guideline...

If 6 mil poly (0.1 perms) is used as the warm side vapor retarder, can OSB + exterior EPS be used together?

- 1 inch of exterior XPS (1.0 perms) is 10x more vapor open - **PASSES**
- 1 inch of exterior EPS (3.0 perms) is 30x more vapor open - **PASSES**
- 1 inch of foil faced polyiso (0.05 perms) is less permeable than the poly - **FAILS**
- 1 inch of mineral wool (100 perms) is 100x more vapor open- **PASSES**

- OSB sheathing (1.0 perms) is exactly 10x more vapor open – **PASSES**
- DensGlass Gold, fire-rated type X (12 perms) is 120x more vapor open – **PASSES**
- OSB sheathing + 1 inch of EPS (0.75 perms total) is 7.5x more vapor open - **FAILS, but...**

The addition of exterior rigid foam over sheathing is often a gray area that requires more analysis.

Section 1 – Building Science Review

If exterior foams are used:

- 1) An adequate amount should be used to meet R-value guidelines (keeps sheathing warm and helps prevent condensation in the wall cavity)
- 2) A more permeable warm-side vapor retarder should be used, class III, to allow the cavity to dry to the inside

Be advised:

In cold climates, a thin application of exterior foam can put the wall in no-man's land – not enough exterior R-value to keep the sheathing warm and condensation free, but perhaps enough vapor resistance to create a vapor sandwich.

Section 1 – Building Science Review

If exterior foams are used:

<i>Climate Zone</i>	<i>Class III vapor retarders permitted for:</i>
Zone Marine 4	Vented cladding over OSB Vented cladding over plywood Vented cladding over fiberboard Vented cladding over [exterior] gypsum [sheathing] Insulated [foam] sheathing with R-value \geq R2.5 over 2x4 wall Insulated [foam] sheathing with R-value \geq R3.75 over 2x6 wall
Zone 5	Vented cladding over OSB Vented cladding over plywood Vented cladding over fiberboard Vented cladding over [exterior] gypsum [sheathing] Insulated [foam] sheathing with R-value \geq R5 over 2x4 wall Insulated [foam] sheathing with R-value \geq R7.5 over 2x6 wall
Zone 6	Vented cladding over fiberboard Vented cladding over [exterior] gypsum [sheathing] Insulated [foam] sheathing with R-value \geq R7.5 over 2x4 wall Insulated [foam] sheathing with R-value \geq R11.25 over 2x6 wall
Zones 7 and 8	Insulated [foam] sheathing with R-value \geq R10 over 2x4 wall Insulated [foam] sheathing with R-value \geq R15 over 2x6 wall

IECC 2007, table 402.5.1

Section 1 – Building Science Review

We've been talking about:
Control Layers

Water Barrier

Air Barrier

Vapor Retarder

Thermal Barrier




Image from Peter Yost

Section 1 – Building Science Review

We've been talking about:
Control Layers

Water Barrier – “physics first (slope, weatherlap, capillary break), chemistry second” (sealants, tapes). High *water* resistance is key, but *vapor* resistance is variable (e.g. Gore-tex)




Image from Peter Yost

Section 1 – Building Science Review

We've been talking about:
Control Layers

Air Barrier – Ability to resist air pressure is key. 100% continuity is vital. Vapor resistance can be variable. Think carefully about its location in the wall cross section and the possibility for air flow within the cavity.




Image from Peter Yost

Section 1 – Building Science Review

We've been talking about:
Control Layers

Vapor Retarder – Vapor resistance is still variable. Needs to be chosen according to climate (direction of vapor drive), location in the wall assembly, and design intent (e.g. desired drying direction).

Continuity is less important:
A 99% continuous vapor retarder is 99% effective.




Image from Peter Yost

Section 1 – Building Science Review

We've been talking about:
Control Layers

Thermal Barrier – Low thermal conductivity is key. Continuity is also important (no thermal bridges).

Ratio of exterior insulation to interior insulation plays a huge role in the moisture dynamics of the wall assembly.





Image from Peter Yost

Section 1 – Building Science Review

The Perfect Wall – Wall design simplified!

- 1) All control layers to the exterior of the structure
- 2) Structure is kept warm and dry
- 3) Air barrier, water barrier, and vapor retarder can be combined into one layer
- 4) Those control layers are protected by the insulation and application is simplified
- 5) Works in any climate zone

Image from Building Science Corp.



Section 2 – Qualitative Moisture Assessment

How is the assembly *designed* to handle moisture?


Section 2 – Qualitative Moisture Assessment

How is the assembly *designed* to handle moisture?

There are a few steps to a qualitative moisture assessment:

1) Describe how the assembly is designed to handle bulk water

- **Identify the water control layer.** Does it rely on perfection? (i.e. face-sealed cladding or caulk)
- Are there redundancies built into the assembly?
- Does the assembly have safe moisture storage potential?
- Is the water control layer durable and protected from damage functions (extreme temps, solar radiation, etc?)
- Is a drainage gap/capillary break provided?



Building Science Corp.

Section 2 – Qualitative Moisture Assessment


How is the assembly *designed* to handle moisture?

There are a few steps to a qualitative moisture assessment:


2) Describe how the assembly is designed to control air leakage

- **Identify the air control layer.** Can it be installed easily in a continuous fashion?
- Is the air barrier a durable (or fragile) material?
- Is the air barrier protected from damage functions?
- Is it located in the right place in the assembly?

MOISTURE MIGRATION BY AIR LEAKAGE



Initial Conditions: The left chamber is at a higher air pressure than the right chamber. Any puncture in the air barrier will result in both air and water vapor molecules migrating to the right chamber.



Equilibrium Conditions: After several seconds, the air/vapor mixture leaks from the left chamber into the right chamber until air pressure equilibrium is reached across both chambers.


Section 2 – Qualitative Moisture Assessment

How is the assembly *designed* to handle moisture?

There are a few steps to a qualitative moisture assessment:

3) Describe how the assembly is designed control diffusion

- **Identify the vapor control layer.**
For cold climates, is it on the warm side?
- Does the assembly avoid creating a vapor sandwich?
- Do interior layers of the assembly have an adequately high drying potential, or is the assembly very impermeable in both directions?




Section 2 – Qualitative Moisture Assessment

How is the assembly *designed* to handle moisture?

There are a few steps to a qualitative moisture assessment:

4) Describe how the assembly is designed to control heat flow

- **Identify the thermal control layer.**
Is it continuous or are there uninsulated spots where condensation could occur?
- Does the insulation help protect control layers from damage functions?
- Does the insulation help keep the sheathing and structure warm and dry?



Section 2 – Qualitative Moisture Assessment

How is the assembly *designed* to handle moisture?

There are a few steps to a qualitative moisture assessment:

- 1) Describe how the assembly is designed to handle bulk water
- 2) Describe how the assembly is designed to control air leakage
- 3) Describe how the assembly is designed control diffusion
- 4) Describe how the assembly is designed to control heat flow


Understand conceptually how the assembly is supposed to work.
then...

Evaluate the design, constructability, and long-term durability

Section 2 – Qualitative Moisture Assessment


Introducing 3 Wall Types:

2x6 w ccSPF and Enduramax




Material	λ [W/(m K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 13 mm	0.080	
ccSPF (R-6.7/inch)	0.021	0.900

6" SIP w brick



Material	λ [W/(m K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 45 mm	0.250	
OSB	0.097	0.900


2x8 w cellulose and fiber cement



Material	λ [W/(m K)]	ϵ
Cellulose	0.040	0.900
Dens Glass Gold	0.161	0.900
Fiber cement - Hardie board	0.301	0.900
Gypsum board	0.161	0.900
XPS	0.029	0.900

Section 2 – Qualitative Moisture Assessment

2x6 with ccSPF and Enduramax




- Water control:** Drained and screened
- brick cladding sheds bulk water
 - drainage grooves built into back of EPS
 - WRB is liquid-applied 3M 2085VP

System has good redundancy
WRB is protected from damage functions
Drainage grooves provide capillary break

But little water storage potential

Section 2 – Qualitative Moisture Assessment

2x6 with ccSPF and Enduramax



Air control: exterior air barrier

- liquid-applied 3M 2085VP (primary)
- closed cell spray foam in stud cavities

System has good redundancy


3M 2085 can be applied in continuous fashion and is well-protected

ccSPF is a very durable air barrier

Location of primary air barrier on exterior of sheathing works well *with air-impermeable cavity insulation*

Section 2 – Qualitative Moisture Assessment

2x6 with ccSPF and Enduramax



Vapor control: ccSPF

- closed cell spray foam in stud cavities

Vapor control is on warm side


Exterior layers of gypsum sheathing and 3M 2085 are vapor open, but EPS + brick is only 3.5x more vapor open than the ccSPF

Sheathing is located between two semi-impermeable layers (which way can it dry?) but has some relief thanks to drainage gap

Outward drying strategy is hampered by exterior foam

Section 2 – Qualitative Moisture Assessment

2x6 with ccSPF and Enduramax



Thermal control: ccSPF plus Enduramax

- closed cell spray foam in stud cavities
- exterior EPS


Spray foam fills cavities completely and exterior EPS help eliminate cold spots/thermal breaks

Exterior insulation helps protect primary air and water barrier

Exterior EPS (2 inches, R-8) is too thin to keep sheathing and structure above dew point during winter conditions

Section 2 – Qualitative Moisture Assessment

2x6 with ccSPF and Enduramax




Overall:

- Water control: 😊
Air control: 😊
Vapor control: 😐
Thermal control: 😊/😐

Material	λ [W/(m·K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 13 mm	0.080	
ccSPF (R-6.7/inch)	0.021	0.900

Section 2 – Qualitative Moisture Assessment

6 inch SIP with brick



Overall:

Water control: drained and screened


Air control: SIP panel w tape/spray foam

Vapor control: SIP panel (consistent semi-impermeable all the way through)

Thermal control: SIP panel (reduced thermal bridging)

Section 2 – Qualitative Moisture Assessment

6 inch SIP with brick



Material	λ [W/(m·K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 45 mm	0.250	
OSB	0.097	0.900

Overall:

Water control:



Air control:



Vapor control:




Thermal control:



Section 2 – Qualitative Moisture Assessment

2x8 with cellulose and fiber cement



Overall:

Water control: no drainage gap, but cellulose has large moisture storage/redistribution potential


Air control: 6 mil poly and dense-pack cellulose

Vapor control: 6 mil poly and 1 inch exterior XPS (possible vapor sandwich)

Thermal control: exterior XPS (R-5) reduces thermal bridging but is too thin to keep sheathing above dew point

Section 2 – Qualitative Moisture Assessment

2x8 with cellulose and fiber cement



Material	λ [W/(m·K)]	ϵ
Cellulose	0.040	0.900
Dens Glass Gold	0.161	0.900
Fiber cement - Hardie board	0.301	0.900
Gypsum board	0.161	0.900
XPS	0.029	0.900

Overall:

Water control:



Air control:



Vapor control:




Thermal control:



Section 2 – Qualitative Moisture Assessment


Which wall is the least moisture safe?:

2x6 w ccSPF and Enduramax




Material	λ [W/(m K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 13 mm	0.080	
ccSPF (R-6.7/inch)	0.021	0.900

6" SIP w brick



Material	λ [W/(m K)]	ϵ
Brick (R-0.1/inch)	1.312	0.900
Dens Glass Gold	0.161	0.900
EPS Type VIII (R-4/inch)	0.036	0.900
Gypsum board	0.161	0.900
Luftschicht, ruhend, horizontal, Dicke: 45 mm	0.250	
OSB	0.097	0.900

2x8 w cellulose and fiber cement



Material	λ [W/(m K)]	ϵ
Cellulose	0.040	0.900
Dens Glass Gold	0.161	0.900
Fiber cement - Hardie board	0.301	0.900
Gypsum board	0.161	0.900
XPS	0.029	0.900

Section 3 – Glaser Analysis

How is the assembly *designed* to handle condensation risk and diffusion?

Section 3 – Glaser Analysis

Start with condensation risk:


Calculate the temperature profile through a wall,
3 options for this:

- 1) Locate a calculator on line, search for “wall gradient calculator”
<http://cwc.ca/resources/wall-thermal-design/>
- 2) Develop your own calculator
- 3) Use calculator that has been developed for the MN B3 program

Section 3 – Glaser Analysis

Calculate the temperature profile through a wall: #1 R-value of each layer


Wall Section Surfaces - R-value through insulation				
surfaces (from inside to outside)				fraction of total (additive)
1	inside air film		R= 0.68	0.02
2	gypsum+latex paint+6mil poly		R= 0.56	0.04
3	cellulose		R= 26.83	0.83
4	DensGlas Gold + Tyvek		R= 0.56	0.85
5	XPS		R= 5.00	0.99
	0		R= 0.00	0.99
	0		R= 0.00	0.99
	0		R= 0.00	0.99
	0		R= 0.00	0.99
	0		R= 0.00	0.99
6	outside air film		R= 0.17	1.00
	total resistance value		R= 33.8	



Section 3 – Glaser Analysis

Calculate the temperature profile through a wall: #2 Temp at each surface


Temperature Profiles - Dewpoint Locator				
surfaces (from inside to outside)				winter (design)
	inside RH %			50%
	inside temperature			68
	1 inside air film			67.0
	2 gypsum+latex paint+6mil poly			66.2
	3 cellulose			27.1
	4 DensGlas Gold + Tyvek			26.2
	5 XPS			18.9
	6 outside air film			18.7
	outside temperature			18.7
	outside RH%			75%
	dewpoint temp			48.6



Typically, outside conditions are set to average winter temp and RH, estimate the likely average interior conditions (temp and RH)


Section 3 – Glaser Analysis

Calculate the temperature profile through a wall: #3 Graph profile



Section 3 – Glaser Analysis

Where a surface temperature is below the dewpoint, there is risk of condensation



Section 3 – Glaser Analysis

The vapor profile is based on the temperature profile, but adds vapor resistance and pressure to each layer.

You need to know additional material properties:


- 1) the permeance (perms) of all membranes
- 2) the permeability (perm in) of all thick materials and air layers

Everything exterior of a vented/ventilated air gap is typically removed. (Effects of many cladding systems cannot be included.)

Section 3 – Glaser Analysis

Calculate the vapor profile through a wall: **#1 Vapor resistance of each layer**


Wall Section Surfaces - vapor resistance, through insulation				
surfaces (from inside to outside)			resistance (reps)	fraction of total (additive)
1	inside air film		R= 0.006	0.000
2	gypsum+latex paint+6mil poly		R= 16.796	0.940
3	cellulose		R= 0.063	0.943
4	DensGlas Gold + Tyvek		R= 0.104	0.949
5	XPS		R= 0.909	1.000
	0		R= 0.000	1.000
	0		R= 0.000	1.000
	0		R= 0.000	1.000
	0		R= 0.000	1.000
	0		R= 0.000	1.000
6	outside air film		R= 0.001	1.000
	total resistance value		R= 17.878	



Section 3 – Glaser Analysis


Calculate the vapor profile through a wall: #2 Vapor pressure at each surface

Vapor Pressure Profile - winter design conditions, through insulation							
surfaces (from inside to outside)				Temp	Saturation vapor pressure (psi)	RH	Initial vapor
	Indoor air			68.0	0.3379	50%	0.1689
	1-2 surface			67.0	0.3265		0.1689
	2-3 surface			66.2	0.3173		0.0456
	3-4 surface			27.1	0.0717		0.0451
	4-5 surface			26.2	0.0693		0.0444
	5-6 surface			18.9	0.0508		0.0377
	Outdoor air			18.7	0.0503	75%	0.0377




Section 3 – Glaser Analysis

Calculate the vapor profile through a wall: #3 Graph profile




Section 3 – Glaser Analysis

Where the initial vapor pressure is above the saturation vapor pressure, moisture will climb towards 100% RH:
little risk in this case




Section 3 – Glaser Analysis

Exterior ply of the SIP panel is below dewpoint – **but what's the risk?**




Section 3 – Glaser Analysis

Exterior ply of the SIP panel is below dewpoint – **but what's the risk?**
– no cavity, no airflow, no available condensation plane in this case




Section 3 – Glaser Analysis

Exterior ply of the SIP panel is above the saturation vapor pressure, moisture will climb towards 100% RH, elevated moisture risk




Section 3 – Glaser Analysis

Gypsum sheathing is below dewpoint – **but what's the risk?** Has a cavity that's filled with ccSPF, no available condensation plane in this case.



Section 3 – Glaser Analysis

Gypsum sheathing is very close to the saturation vapor pressure. Possible elevated moisture risk.



Section 4 – WUFI Analysis

How is the assembly *predicted to perform* in terms of moisture?

Section 4 – WUFI Analysis

Project Inputs Run Outputs Options Database Result Analysis ?

Project

- Case: #1 #1 Test (Act. Case)
 - Component
 - Assembly/Monitor Positions
 - Orientation
 - Surface Transfer Coeff.
 - Initial Conditions
 - Control
 - Climate
 - Quick Graph
 - Total Water Content
 - Water Content in Layer
 - Mon.Pos. Temp/Humidity
 - 0.00 m (Exterior Surface)
 - 1.75 m
 - 2.32 m
 - 10.65 m (Interior Surface)
 - Mon.Pos. Isoleths
 - 0.00 m (Exterior Surface)
 - 1.75 m
 - 2.32 m
 - 10.65 m (Interior Surface)
- Case: 2 #2
 - Component
 - Assembly/Monitor Positions
 - Orientation
 - Surface Transfer Coeff.
 - Initial Conditions
 - Control
 - Climate
 - Quick Graph

Case: #1 Test

Assembly/Monitor Positions | Orientation/Inclination/Height | Surface Transfer Coeff. | Initial Conditions

Layer Name: Gypsum Board (USA) | Thckn. [in]: 0.625

Exterior (Left Side): 0.19681, 0.00, 0.00, 0.19685 | 7.25 | Interior (Right Side): 0.00, 0.625

Material Data

Sources, Sinks

New Layer

Duplicate

Delete

Edit Assembly by:
 Graph
 Table

Assign from: Material Database | Example Cases


Grid: Automatic (I) | 70 | Medium | Copy Auto. Grid Def. for Manual Editing

Total Thickness: Thickness: 10.65 in | Total Thermal Performance: R-Value: 38.52 h ft² °F/Btu | U-Value: 0.025 Btu/h ft² °F

Units: IP | Last Calculation: 2/28/2018

Section 4 – WUFI Analysis


WUFI attempts to predict actual moisture levels in all layers of a wall (or roof) assembly by modeling almost all relevant forces and conditions dynamically, hour by hour.



Section 4 – WUFI Analysis

Hourly exterior environmental conditions including...


- Temperature
- Relative humidity
- Precipitation
- Solar radiation
- Wind



Section 4 – WUFI Analysis

Hourly interior environmental conditions including...

- Temperature
- Relative humidity
- Internal heat gains
- Internal moisture gains
- HVAC equipment
- Setpoints/schedules
- Ventilation rates
- Air leakage rates




Section 4 – WUFI Analysis

Building Conditions

- Orientation
- Inclination
- Height
- Rain exposure
- Shading


Case: #1

Orientation



South

Inclination



Inclination [°] 90

Building Height/Driving Rain Coefficients

Rain load calculation according to ASHRAE Standard 160

rain exposure factor (FE) 1.2

rain deposition factor (FD) 0.5

Building Height [ft] >10 and <20

Exposure Category Medium


Walls below a low-slope roof

Note:
Rain Load =
 $\text{Rain} * \text{FE} * \text{FD} * 0.2 \text{ s/m} * \text{Wind Velocity}$

Section 4 – WUFI Analysis

Material Properties – stored in large database of stock materials

- Density
- Heat conductivity
- Heat capacity
- Permeability
- Moisture storage
- Capillarity
- Others...



Section 4 – WUFI Analysis

Moisture dynamics possible to model

- Bulk water leakage
- Capillary drive
- Air leakage
- Diffusion
- Moisture storage
- Initial moisture conditions (wet building materials)
- Surface treatments (different moisture adsorption characteristics, colors, permeability, etc)

Dynamics not possible to model

- Convection
- 2D moisture flow (only clear wall sections are modeled)

Section 4 – WUFI Analysis

Air leakage rates specified in special air layers

Water leakage rates specified within certain material layers

“Monitors” set in critical layers to track conditions

The screenshot displays the WUFI software interface for configuring a wall assembly. The main window is titled "Assembly/Monitor Positions" and shows a cross-section of a wall with various layers and monitors.

Assembly/Monitor Positions

Layer Name	Thickn. [in]
Gypsum Board (USA)	0.625

Exterior (Left Side) 0.19681 0.00 0.19685 Interior (Right Side) 7.25 0.03 0.625

The interface includes several control panels on the right side:

- Material Data** (document icon)
- Sources, Sinks** (lightbulb and faucet icon)
- New Layer** (+ icon)
- Duplicate** (copy icon)
- Delete** (trash icon)
- Edit Assembly by:** Graph Table

At the bottom, there are summary statistics:

- Assign from:** Material Database, Example Cases
- Grid:** Automatic (I), 70, Medium
- Total Thickness:** Thickness: 10.65 in
- Total Thermal Performance:** R-Value: 38.52 h ft² °F/Btu
- U-Value:** 0.025 Btu/h ft² °F



Section 4 – WUFI Analysis

There are many ways to analyze WUFI results.

MC \geq 18% is problematic for wood-based materials.

“Sustained” RH \geq 80% can initiate mold growth, but temp must be $> 32^{\circ}\text{F}$

3 years of results typical, to see trends





Section 4 – WUFI Analysis

For 2x8 w cellulose and fiber cement:

Despite exterior XPS, temps in sheathing are still frequently below freezing.

RH spikes in winter (sign of a wall that dries to the outside), but appears to be safely below 80% RH





Section 4 – WUFI Analysis

For 6" SIP w brick:

Sheathing is colder w/out exterior foam, but...

RH is actually lower in sheathing thanks to vented cavity and lack of semi-impermeable XPS

(Recall, Glaser predicted worse performance)





Section 4 – WUFI Analysis

For 2x6 w ccSPF and
Enduramax:

Sheathing is warmer
thanks to exterior EPS
(R-8)


RH is quite similar,
slightly better than SIP

(Recall, Glaser predicted
better performance than
SIP too)



The 4 Types of Moisture Risk Analysis


1) Qualitative moisture assessment



2) Static diffusion and condensation risk assessment (Glaser analysis)




3) Dynamic simulated hygrothermal performance (WUFI analysis)



Summary and Recap


1) Summary – 2x8 w cellulose and fiber cement



	Qualitative	Glaser	WUFI
Water control:	☹️	-	☹️
Air control/condensation:	☹️/☠️	☹️	☹️
Vapor control:	☹️	😊	☹️
Thermal control:	☹️	-	-

Different tools provide different answers. Judgement is needed.

Summary and Recap




1) Summary – 6” SIP with brick

	Qualitative	Glaser	WUFI
Water control:	😊	-	😊
Air control/condensation:	😊/😞	😞	😊
Vapor control:	😊	😞	😊
Thermal control:	😞	-	-

Different tools provide different answers. Judgement is needed.

Summary and Recap



1) Summary – 2x6 with ccSPF and Enduramax

	Qualitative	Glaser	WUFI
Water control:	😊	-	😊
Air control/condensation:	😊	😞	😊
Vapor control:	😐	😐	😊
Thermal control:	😊/😐	-	-

Different tools provide different answers. Judgement is needed.

Summary and Recap

1) Qualitative moisture assessment



Encourages thoughtful analysis of all elements impacting moisture performance, and understanding of design intent (regarding moisture)



Adds important considerations of material durability, constructability, and field experience (otherwise missed by models).



Rarely provides definitive answers.

Summary and Recap

2) Static diffusion and condensation risk assessment (Glaser analysis)



Offers simple comparisons between wall assemblies that can be used quickly during design phase to identify and reduce condensation and diffusion risks. It is a quick design tool.



Only considers behavior at one set of conditions (a given temp and RH). Best for comparison purposes, not prediction.



Does not incorporate many important elements related to moisture behavior – water leakage, air leakage, and capillary drive



Cannot model impacts of vented/ventilated cladding systems



Does not predict ultimate moisture levels, safety, or failure

Summary and Recap

3) Dynamic simulated hygrothermal performance



Attempts to predict actual moisture levels through all layers of wall and roof assemblies, affording greater certainty regarding success or failure



Can model almost the complete range of moisture drive mechanisms including rain, solar gains, bulk water leakage, air leakage, capillary drive, diffusion, and storage.



Dynamic, hour by hour modeling for a variety of climates can help pinpoint reasons and times of failures.



Basic simulations are easy to run, but accuracy requires knowledgeable, experienced users and more time to refine material properties.



There is still debate about the ultimate accuracy of WUFI, especially for cavity walls with possible air flow and roofs

Thanks for your attention!

Contact info:

Rolf Jacobson

jaco0630@umn.edu

612 301 1601

Center for Sustainable Building Research

University of Minnesota